
Caution Always diconnect electrics before commencing any installation.



Manhole Riser

- Take off access cover.
 Diconnect any electrics or pipework if necessary.
- Apply a bead of silicone around the inside of the radius at the bottom of the riser.
- Place riser over manhole, lining up the locking bolts, and push down.
- Screw the riser to the manhole.
 One screw in each corner and 1
 in the center of each side. 8 in total.
- Replace the bolts in the access cover for the longer bolts supplied and reverse so they poins inwards as shown.
- Reconnect any electrics and pipework, if necessary.
 Extension pieces are supplied.
- Slide access cover onto riser so the bolts extend into the holes on the top of the riser and lock the front to secure.

Desluding Cover Riser

- A. Take off desludging Cover
- Apply a bead of silicone around the inside of both sides the joiner to seal.
- C. Put joiner on to pipe already on tank.
- D. Put on extension piece of pipe.
- E. Apply another bead of silicone to the outside of the joiner to ensure water tight seal
- F. Place desludging cover onto pipe and secure as before.





